



IMPORTANT

Remove jumper between terminal I & C before connecting interlocks. Wire in accordance with local & Canadian Electrical codes. Read instructions carefully before wiring and operating.

Frame shown in heavy line represents Thermolec Electric Coil. All wiring outside this frame are "typical external wiring by others".

LEGEND

- A Automatic Reset Cut Out
- C1,C2 Operating Contactors
- CM Back-up Contactor to Manual
- DISC Disconnect Switch
- D46 Electronic Step Controller
- F Fuse
- M Manual Reset Cut Out
- OL Overload Relay
- PDS Pressure Differential Switch
- PES Pressure Electric Switch
- PL Pilot Light
- R Relay
- SSR Solid State Relay
- T Control Circuit Transformer
- TH Thermostat
- THR Thermal Relay
- DT Duct Thermostat
- RT Room Thermostat

TITLE/TITRE



THERMOLEC

MONTREAL - CANADA

LTEE
LTD

DRAWING NO. 3B5A-7M4U-B600-0000

DATE

PER